



A Division of Cintek System, Inc.

### **Installation over Radiant Heat Sub-floors**

Prime flooring may be installed over water-based radiant-heated sub-floors according to installation instructions, provided the surface temperature of the system does not exceed 75 degrees F (24 degrees C).

**IMPORTANT:** Due to the speed of sudden temperature changes, which has potential to negatively affect the flooring construction, it is not recommended to install over electrical radiant heating systems. This will not be covered by the manufacturer's warranty.